

<b>DTC</b>	<b>34 (2)</b>	<b>Turbocharger system malfunction</b>
------------	---------------	--

<b>DTC</b>	<b>34 (3)</b>	<b>Turbocharger stick detected (Close)</b>
------------	---------------	--

<b>DTC</b>	<b>34 (4)</b>	<b>Turbocharger stick detected (Open)</b>
------------	---------------	---

## CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
34 (2)	When the condition that the turbocharger pressure exceeds the standard value for 0.5 sec. or more is detected.	<ul style="list-style-type: none"> <li>• VNT valve</li> <li>• Turbocharger</li> <li>• EGR valve</li> <li>• Air flow meter</li> <li>• Engine ECU</li> </ul>
34 (3) (4)	When the condition that for 60 sec. or more the turbocharger pressure is 20 kPa (0.2 kgf/cm <sup>2</sup> , 1.4 psi) or more above the value that is set based on the engine revolution and the amount of fuel injection is detected.	

## INSPECTION PROCEDURE

HINT:

If DTC 35 is output simultaneously, first troubleshoot DTC 35.

### When using hand-held tester:

<b>1</b>	<b>Check connection of vacuum hose.</b>
----------	---

**NG**

**Repair or replace.**

**OK**

## 2 Check vacuum between turbocharger and E-VRV for intake pressure change at 900 rpm.

### PREPARATION:

- Using a 3-way connector, connect a vacuum gauge to the hose between the E-VRV and turbocharger.
- Warm up the engine to above 80°C (176°F).

### CHECK:

Check the vacuum at 900 rpm.

### RESULT:


Type	Vacuum
I	0 kPa (0 mmHg, in. Hg) – 50 kPa (375 mmHg, 14.8 in. Hg)
II	Above 50 kPa (375 mmHg, 14.8 in. Hg)

Type II

Go to step 7.

Type I

## 3 Check voltage between terminal VNT of engine ECU connector and body ground.



### PREPARATION:


- Remove the glove compartment door.
- Turn the ignition switch ON.

### CHECK:

Measure the voltage between terminal VNT of the engine ECU connector and body ground.

### OK:

Voltage: 9 – 14 V



### Reference: INSPECTION USING OSCILLOSCOPE

During EGR system is ON (engine speed 900 rpm), check the waveform between terminals VNT and E1 of engine ECU connector.

### HINT:


The correct waveform is as shown.

NG

Go to step 5.

OK

#### 4 Check operation of E-VRV for intake pressure change.



#### PREPARATION:

- Disconnect the vacuum hoses from the E-VRV.
- Connect the hand-held tester to the DLC3.
- Turn the ignition switch ON and the push hand-held tester main switch ON.
- Select the ACTIVE TEST mode on the hand-held tester.

#### CHECK:

Check the operation of the E-VRV when it is operated by the hand-held tester.

#### OK:

**E-VRV ON:**

Air from port E flows out through port F.

**E-VRV OFF:**

Air from port E flows out through air filter.

OK

Go to step 7.

NG

#### 5 Check E-VRV for intake pressure change (See page TC-15)

NG

Replace E-VRV.

OK

#### 6 Check for open and short in harness and connector between E-VRV and engine ECU, and E-VRV and EFI main relay (Marking: EFI) (See page IN-19)

NG

Repair or replace harness or connector.

OK

7	Check turbocharger assembly (See page TC-1).
---	--

NG	Replace turbocharger.
----	-----------------------

OK

8	Check EGR valve (See page EC-2).
---	----------------------------------

NG	Replace EGR valve.
----	--------------------

OK

9	Check air flow meter (See page DI-26).
---	--

NG	Replace air flow meter.
----	-------------------------

OK

Check and replace engine ECU (See page IN-19).
--

**When not using hand-held tester:**

1	Check the connection of vacuum hose.
---	--------------------------------------

NG	Repair or replace.
----	--------------------

OK

## 2 Check vacuum between turbocharger and E-VRV for intake pressure change at 900 rpm.

### PREPARATION:

- Using a 3-way connector, connect a vacuum gauge to the hose between the E-VRV and turbocharger.
- Warm up the engine to above 80°C (176°F).

### CHECK:

Check the vacuum at 900 rpm.

### RESULT:

Type	Vacuum
I	0 kPa (0 mmHg, in. Hg) – 50 kPa (375 mmHg, 14.8 in. Hg)
II	Above 50 kPa (375 mmHg, 14.8 in. Hg)


Type II

Go to step 6.


Type I

## 3 Check operation of E-VRV.

E-VRV: ON



E-VRV: OFF



A18530

### PREPARATION:

- Remove the glove compartment door.
- Disconnect the E3 connector from the engine ECU.
- Turn the ignition switch ON.

### CHECK:

Check the E-VRV operation.

- Connect between terminal VNT of the engine ECU connector and body ground (ON).
- Disconnect between terminal VNT of the engine ECU connector and body ground (OFF).

### OK:

#### E-VRV ON:

Air from port E flows out through port F.

#### E-VRV OFF:

Air from port E flows out through air filter.

OK

Go to step 6.

NG

4	Check E-VRV for intake pressure change (See page ED-10).
---	--

NG	Replace E-VRV.
----	----------------

OK

5	Check for open and short in harness and connector between E-VRV and engine ECU, and E-VRV and EFI main relay (Marking: EFI) (See page IN-19).
---	---

NG	Repair or replace harness or connector.
----	---

OK

6	Check turbocharger assembly (See page TC-1).
---	--

NG	Replace turbocharger.
----	-----------------------

OK

7	Check EGR valve (See page EC-2).
---	----------------------------------

NG	Replace EGR valve.
----	--------------------

OK

8	Check air flow meter (See page DI-26).
---	--

NG	Replace air flow meter.
----	-------------------------

OK
----

Check and replace engine ECU (See page IN-19).
--