







System Outline

Depending on the transfer shift actuator status and ADD actuator (1GR–FE) status, the 4WD control ECU drives the transfer shift actuator and ADD actuator (1GR–FE) to electrically change the gear position selected by the driver according to vehicle speed signal and neutral start switch signal.

1. Shift Select Control

Shifting from H2 into H4 position (1GR-FE)

When the 4WD control switch is turned from H2 into H4, this signal is input into 4WD control ECU (TERMINAL 2–4). Then, the 4WD control ECU moves the 2–4 select motor (TERMINAL 2, TERMINAL 1) in the transfer shift actuator until the shift fork shaft shifts to the diff. free position, performing a shift into H4 position

Switching diff. lock ON when in H4 position.

When the diff. lock switch is turned ON with the 4WD control switch in H4 position, this signal is input into the 4WD control ECU (TERMINAL DL). Then, the 4WD control ECU drives the 2–4 select motor (TERMINAL 2, TERMINAL 1) in the transfer shift actuator until the shift fork shaft shifts to the diff. lock position, locking it in H4 position with the diff. lock.

Shifting from H4 into L4 position

When the 4WD control switch is turned from H4 into L4, this signal is input into 4WD control ECU (TERMINAL LO). Then, the 4WD control ECU drives the H–L select motor (TERMINAL 8, TERMINAL 7) in the transfer shift actuator, shifting the shift fork shaft, performing a shift into L4 position.

Switching diff. lock ON when in L4 position.

When the diff. lock switch is turned ON with the 4WD control switch in L4 position, this signal is input into the 4WD control ECU (TERMINAL DL). Then, the 4WD control ECU drives the 2–4 select motor (TERMINAL 2, TERMINAL 1) in the transfer shift actuator until the shift fork shaft shifts to the diff. lock position, locking it in L4 position with the diff. lock.

2. Function of Limit Switch

H4L limit switch (TERMINAL 12 and TERMINAL 11 of transfer shift actuator)

The H4L limit switch in the transfer shift actuator feeds back the current shift position status (H4 or L4) information, which is based on the ON/OFF combination of the two switches, to the 4WD control ECU.

4WD limit switch (TERMINAL 3 (1GR-FE), TERMINAL 4 and TERMINAL 5 of transfer shift actuator)

The 4WD limit switch in the transfer shift actuator feeds back the current shift position status (H2 or H4) (1GR-FE) and diff. lock or diff. free status information, which is based on the ON/OFF combination of the two (2UZ-FE) or three (1GR-FE) switches, to the 4WD control ECU.

ADD limit switch (TERMINAL 6 and TERMINAL 5 of ADD actuator) (1GR-FE)

The ADD limit switch in the ADD actuator feeds back the current front diff. lock or free status information, which is based on the ON/OFF combination of the two switches, to the 4WD control ECU.

3. Shift Limit Control

The 4WD control ECU interrupts the shift select control and gives the driver a warning by means of buzzer (Integrated into the ECU) sound and blinking indicator light on the combination meter when the following shift change conditions exist.

The warning, however, can be canceled when the 4WD control switch is canceled and the switch position is returned to the original position before the warning occurred.

- * Shift change (1GR–FE) from H2 into H4 with vehicle traveling at a speed reaching or exceeding 100 km/h (Buzzer sound and blinking 4WD and center diff. lock indicator lights)
- * Shift change from H4 into L4 with vehicle traveling at a speed reaching or exceeding 5 km/h but with the A/T shift position N range (Buzzer sound and blinking L4 indicator light)

4. ADD Actuator Control (1GR-FE)

When switching over between H2 (2WD) and H4 (4WD), the 4WD control ECU controls the way in which power is supplied to the ADD motor in the ADD actuator, as shown below, to run the ADD motor in normal or reverse direction, thereby changing the status of the front diff. from free to lock, or vice versa.

For locking front diff. TERMINAL DM1 +B

TERMINAL DM2 GROUND

For unlocking front diff. TERMINAL DM1 GROUND

TERMINAL DM2 +B

: Parts Location

Code		See Page	Code		See Page	Code		See Page
A11		34 (1GR-FE)	J9 B		38	J32	В	38
C9	В	37	J10	Α	38	J33	Α	38
C10	С	37	J11	В	38	J34	В	38
C11	D	37	J14	Α	38	J37		38
D4		37	J15	В	38	P1		33 (2UZ-FE)
E6		37	J20		38	[35 (1GR-FE)
F9	Α	37	J2	24	38	S28		33 (2UZ-FE)
F10	В	37	J2	25	38			35 (1GR-FE)
F11		37	J28		38	- T3		33 (2UZ-FE)
J5		38	J29 A		38			35 (1GR-FE)
J7		38	J30	В	38			
J8	Α	38	J31	Α	38			

: Relay Blocks

	Code	See Page	Relay Blocks (Relay Block Location)
I	2	22	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1G		
1J	25	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
1K		
3D	28	Instrument Panel Wire and Center J/B (Instrument Panel Brace RH)

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
EC1	45 (1GR-FE)	Engine Wire and Differential Wire (Near the Front Differential)	
IC2 46		Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)	
IC4	40	monument and vine and Engine Noon Main vine (Lett Nok Fanet)	
II1	46	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Brace LH)	
IM1	47	Engine Wire and Instrument Panel Wire (Right Side of Blower Unit)	
IM2] "'	Linguise vivile and instrument i arise vivile (ringuit side of blower offilt)	

: Ground Points

Code	See Page	Ground Points Location
ED	44 (2UZ-FE)	Left Bank Cylinder Head
EE	44 (2UZ-FE)	Rear Side of Cylinder Block
""	45 (1GR-FE)	Rear Side of Right Bank Cylinder Block
EF	45 (1GR-FE)	Rear Side of Left Bank Cylinder Block
IG	46	Left Kick Panel
II	46	Instrument Panel Brace RH
IK	46	Right Kick Panel