

## TROUBLESHOOTING w VOLT OHMMETER


**HINT:** Because the following troubleshooting procedures are designed for inspection of each separate system, the actual troubleshooting procedure may vary somewhat.


However, please refer to these procedures and troubleshoot, conforming to the inspection methods described.

For example, it is better to first make a simple check of the fuses, fusible links and connecting condition of the connectors before making your inspection according to the procedures listed.

The following troubleshooting procedures are based on the supposition that the trouble lies in either a short or open circuit in a component outside the computer or a short circuit within the computer. If engine trouble occurs even though proper operating voltage is detected in the computer connector, then the engine control module is faulty and should be replaced.

## FUSES AND FUSIBLE LINK LOCATION





## MFI SYSTEM CHECK PROCEDURE

### HINT:

- Do all voltage measurements with the connectors connected.
- Verify that the battery voltage is 11 V or more when the ignition switch is in 'ON' position.

Using a voltmeter with high impedance (10kΩ/V minimum), measure the voltage at each terminal of the wiring connectors.

## ECM Terminals

Symbol	Terminal Name	Symbol	Terminal Name	Symbol	Terminal Name
NE	DISTRIBUTOR	VC	VOLUME AIR FLOW METER	BATT	BATTERY e +
G⊖	DISTRIBUTOR	E2	SENSOR GROUND	+B	EFI MAIN RELAY
G1	DISTRIBUTOR	VS	VOLUME AIR FLOW METER -		-
G2	DISTRIBUTOR	*3OX2	SUB HEATED OXYGEN SENSOR	+B1	EFI MAIN RELAY
IGF	IGNITER	THA	INTAKE AIR TEMP. SENSOR		-
*1SPD2	VEHICLE SPEED SENSOR	VTA	THROTTLE POSITION SENSOR		-
*2S4	TCM SOLENOID	THW	ENGINE COOLANT TEMP. SENSOR	*1OIL	A/T OIL TEMP. WARNING LIGHT
*1L	PAR/NEUTRAL POSITION SWITCH	IDL	THROTTLE POSITION SENSOR	E21	SENSOR GROUND
*1S3	TCM SOLENOID	KNK	KNOCK SENSOR	W	MALFUNCTION INDICATOR LAMP
*12	PARK/NEUTRAL POSITION SWITCH	THG	EGR GAS TEMP. SENSOR	*1OD2	O/D MAIN SWITCH
*1S2	TCM SOLENOID	OX1	HEATED OXYGEN SENSOR	STP	STOP LIGHT SWITCH
*1N	PARK/NEUTRAL POSITION SWITCH	*2THO2	T/F FLUID TEMP. SENSOR	SEL2	-
*1S1	TCM SOLENOID	*2THO1	4WD OIL TEMP. SENSOR	*1P	PATTERN SELECT SWITCH
*2L4	TRANSFER POSITION SWITCH	TE1	DLC 1	SEL1	-
FPU	VSV (for FPU)	VF	DLC 1	*44WD	4WD SWITCH
IGT	IGNITER	TE2	DLC 1	ACT	A/C AMPLIFIER
STJ	COLD START INJECTOR		-	SPD1	VEHICLE SPEED SENSOR
EGR	VSV (for EGR)		-	*1DG	DLC1
HT1	HEATED OXYGEN SENSOR		-	A/C	A/C MAGNET SWITCH
AS	VSV (tot PAIR)		-	*1OD1	CRUISE CONTROL ECU
E1	ENGINE GROUND		-	STA	STARTER SWITCH
ACV	VSV (for A/C)		-	*3HT2	SUB HEATED OXYGEN SENSOR
#10	INJECTOR		-		-
#20	INJECTOR		-		-
E01	ENGINE GROUND		-		-
E02	ENGINE GROUND		-		-

\*1: A/T only \*2: 4WD A/T only \*3: California only \*4: 4WD only  
Engine Control Module (ECM) Terminals

E01	#10	E1	HT1	STJ	FPU	S1	S2	S3	S4	IGF	G1	NE	VF	THO1	OX1	KNK	THW	THA	VS	VC	STA	A/C	SPD1	4WD	P	STP	W	OIL			BATT
E02	#20	ACV	AS	EGR	IGT	L4	N	2	L	SPD2	G2	G⊖	TE2	TE1	THO2	THG	IDL	VTA	OX2	E2	HT2	OD1	DG	ACT	SEL1	SEL2	OD2	E21		+B1	+B

# ECM Wiring Connectors Voltage


No.	Terminals	Condition		STD voltage	See page
1	BATT — E1	—		9 — 14	EG2-186
	+B — E1	Ignition SW ON			
	+B1 — E2				
2	IDL — E2 (E21)	Ignition SW ON	Throttle valve open	9 — 14	EG2-188
	VC — E2 (E21)		—	4.5 — 5.5	
	VTA — E2 (E21)		Throttle valve fully closed (Throttle opener must be cancelled first)	0.3 — 0.8	
			Throttle valve fully open	3.2 — 4.9	
3	VC — E2 (E21)	Ignition SW ON	—	4.5 — 5.5	EG2-190
	VS — E2 (E21)		Measuring plate fully closed	4.0 — 5.5	
			Measuring plate fully open	0.2 — 0.5	
			Idling	2.3 — 2.8	
		3,000 rpm	0.3 — 1.0		
	THA — E2 (E21)	Ignition SW ON	Intake air temperature 20°C (68°F)	0.5 — 3.4	
4	THW — E2 (E21)	Ignition SW ON	Engine coolant temperature 80°C (176 °F)	0.2 — 1.0	EG2-192
5	STA — E1	Cranking		6 V or more	EG2-193
6	#10 — E01 #20 — E02	Ignition SW ON		9 — 14	EG2-194
7	IGT — E1	Idling		Pulse generation	EG2-195
8	W — E1	No trouble (malfunction indicator lamp off) and engine running		9 — 14	EG2-196
9	STJ — E1	Cranking	Engine coolant temperature 80°C (176°F)	6 V or more	EG2-197
10	STP — E1	Stop light switch ON		7.5 — 14	EG2-198

## Engine Control Module (ECM) Terminals


E01 #10 E1 HT1 STJ FPU S1 S2 S3 S4 IGF G1 NE													VF TH01 OX1 KNK THW THA VS VC								STA A/C SPD1 4WD P STP W OIL / / BATT										
E02 #20 ACV AS EGR IGT L4 N 2 L SPD2 G2 G⊖													TE2 TE1 TH02 THG IDL VTA OX2 E2								HT2 OD1 DG ACT SEL1 SEL2 OD2 E21 / / +B1 +B										

FI2796


No.	Terminals	Trouble	Condition	STD Voltage
1	BATT – E1	No voltage	--	9 – 14 V
	+ B – E1		Ignition switch ON	
	+ B1 – E1			




FI5974



FI3714



FI2754



FI3502

#### • BATT -E1

(1) There is no voltage between ECM terminals BATT and E1.

(2) Check that there is voltage between ECM terminal BATT and body ground.

NO

OK

(3) Check wiring between ECM terminal E1 and body ground.

OK

BAD

Try another ECM.

Repair or replace.

Check fuse and fusible link.

BAD




Replace.

OK

Check wiring between fuse and ECM.

BAD

Repair or replace.



# • +B(+B1)-E1

(1) There is no voltage between ECM terminals + B (+ B1) and E1. (IG SW ON)

(2) Check that there is voltage between ECM terminal + B (+ B1) and body ground. (IG SW ON)

NO

OK

(3) Check wiring between ECM terminal E1 and body ground.

OK

BAD

Try another ECM.

Repair or replace.

Check fuse, fusible link and ignition switch.

BAD

Repair or replace.

OK

Check EF I main relay.

BAD

Replace.

OK

Check wiring between EFI main relay and battery.

BAD

Repair or replace.



OK

Check wiring between EFI main relay and ECM terminal + B (+ B1).

BAD

Repair or replace.

No.	Terminals	Trouble	Condition		STD Voltage
2	IDL – E2 (E21)	No voltage	Ignition switch ON	Throttle valve open	9 – 14 V
	VC – E2 (E21)			–	4.5 – 5.5 V
	VTA – E2 (E21)			Throttle valve fully dosed (Throttle opener must be cancelled first)	0.3 – 0.8 V
				Throttle valve fully open	3.2 – 4.9 V



### • IDL - E2 (E21)

(1) There is no voltage between ECM terminals IDL and E2 (E21).  
(IG SW ON) (Throttle valve open)

(2) Check that there is voltage between ECM terminal + B1 (+B) and body ground. (IG SW ON)

NO

Refer to No. 1.

BAD

Replace or repair.

OK

OK

Check wiring between ECM terminal E1 and body ground.

OK

BAD

Replace or repair.

BAD

(3) Check throttle position sensor.

BAD



Replace or repair throttle position sensor.






OK

Check wiring between ECM and throttle position sensor.


OK

Try another ECM.






### • VC - E2 (E21)




### • VTA-E2 (E21)




No.	Terminals	Trouble	Condition		STD Voltage
3	VC – E2 (E21)	No voltage	Ignition SW ON	—	4.5 – 5.5 V
	Measuring plate fully closed			4.0 – 5.5 V	
	Measuring plate fully open			0.2 – 0.5 V	
	VS – E2 (E21)		Idling		2.3 – 2.8 V
	THA – E2 (E21)		10 SW ON	Intake air temperature 20°C (68°F)	0.5 – 3.4 V


Volume Air Flow Meter




F16069



F13900




F13898








F13828


### • VC - E2 (E21)








### • VS - E2 (E21)




### • THA - E2 (E21)



No.	Terminals	Trouble	Condition		STD Voltage
4	THW - E2 (E21)	No volts	Ignition switch ON	Engine coolant temperature 80°C (176°F)	0.2 - 1.0 V

FI5971



(1) There is no voltage between ECM terminals THW and E2 (E21).  
(IG SW ON)

(2) Check that there is voltage between ECM terminal + B ( +B1) and body ground. (IG SW ON)

OK

NO

Refer to No. 1.

Check wiring between ECM terminal E1 and body ground.

OK

SAD

(3) Check engine coolant temp. sensor.

Repair or replace.

BAD

Replace engine coolant temp. sensor.

OK



Check wiring between ECM and engine coolant temp. sensor.

OK


Try another ECM.

BAD




Repair or replace.



No.	Terminals	Trouble	Condition	STD Voltage
5	STA - E1	No voltage	Cranking	6 V or more



P03018



(1) There is no voltage between ECM terminals STA and E1 (IG SW START)

Check starter operation.

OK

Check wiring between ECM terminal STA and starter terminal 50.

OK

Repair or replace.

BAD

(2) Check wiring between ECM terminal E1 and body ground.

BAD

Repair or replace.

Check fusible link, battery, wiring and ignition switch.

BAD

Repair or replace.

OK



(3) Check that there is voltage at terminal 50 of starter. (IG SW START) STD voltage: 6 V or more

OK

Check starter.

NO

Check wiring between ignition switch ST1 terminal and starter terminal 50.



(1) There is no voltage between ECM terminals # 10 and/or # 20 and E01 and/or E02. (IG SW ON)

(2) Check that there is voltage between ECM terminal # 10 and/or # 20 and body ground.

NO

OK

Check wiring between ECM terminal E01 and/or E02 and body ground.

OK

Try another ECM.

BAD

Repair or replace.

Check fusible link and ignition switch.

BAD

Repair or replace.

OK

(3) Check resistance of magnetic coil in each injector

STD resistance: 13.4 - 14.2  $\Omega$

OK



NO



Replace injector.

Check wiring between ECM terminal # 10 and/or # 20 and battery.

BAD

Repair or replace.





(1) There is no voltage between ECM terminals IGT and E1. **(idling)**

(2) Check that there is voltage between ECM terminal IGT and body ground. **(Idling)**

OK

Check wiring between ECM terminal E1 and body ground.

BAD

Refer to No. 1.

BAD

Repair or replace.

OK

Check wiring between igniter and distributor.

BAD

Repair or replace.

OK

Check distributor.

BAD

Replace.

OK

Check wiring between ECM and igniter.

BAD

Repair or replace.

OK



Check igniter.






BAD

Repair or replace.


OK

Try another ECM.







No.	Terminals	Trouble	Condition		STD Voltage
9	STJ - E1	No voltage	Cranking	Engine coolant temperature 80°C (176°F)	6 V or more




F13893



F13523



F13898



P10005

(1) There is no voltage between ECM terminals STJ and E1  
(IG SW START)

(2) Check that there is voltage between ECM terminal +B (+B1)  
Wand body ground. (IG SW ON)

OK

NO

(3) Check cold start injector

BAD

OK

Refer to No. 1.

Replace cold start injector.

Check wiring between ECM and cold start injector.

OK





BAD

Check wiring between ECM terminal E1 and body ground.

OK

Try another ECM.

Repair or replace wiring.



(1) There is no voltage between ECM terminals STP and E1.

(2) Check that there is voltage between ECM terminal STP and body ground when the brake pedal is depressed:

NO

OK

(3) Check wiring between ECM terminal E1 and body ground.

OK

BAD

Try another ECM.

Repair or replace.

Check STOP fuse (15 A) and stop light switch.

BAD

Repair or replace.


OK

Check wiring between ECM terminal STP and battery.


BAD

Repair or replace.





FI6077



FI3501

(1) There is no voltage between ECM terminals VF1 and E1.

Check that there is voltage between ECM terminal VF and body ground.

NO OK

Check wiring between ECM terminal E1 and body ground.

OK

Try another ECM.

BAD

Repair or replace.

Is air leaking into air induction system?

YES Repair air leak.

NO

Check spark plugs.

BAD Repair or replace.

OK



Check distributor and ignition system.


BAD Repair or replace.

OK


CONTINUED ON PAGE [EG2-200](#)

CONTINUED FROM PAGE EG2-199





FI3895



FI3907


(1) There is no voltage between ECM terminals THG and E2 (E21)  
(Engine running at 2,000 rpm)

(2) Check that there is voltage between ECM terminal +B (+B1) and body ground. (IG SW ON)

OK

NO

Refer to No. 1.



FI3898

Check wiring between ECM terminal E1 and body ground.

OK

BAD

Repair or replace.

Check EGR system.

BAD

Repair or replace.

OK

(3) Check EGR gas temperature sensor.

BAD

Replace EGR gas temperature sensor.

OK


Check wiring between ECM and EGR gas temperature sensor.

OK

Try another ECM.

BAD

Repair or replace.



FI2674