

PROCEDURE

1.INSPECT TIRE


Click here [Suspension>TIRE / WHEEL>TIRE AND WHEEL SYSTEM>INSPECTION](#)

2.MEASURE VEHICLE HEIGHT

NOTICE:

- Before inspecting the wheel alignment, adjust the vehicle height to the specification.
- The standard value shown here is a value that is used for adjusting the wheel alignment and does not indicate the height of an actual vehicle.

a.



Press down on the vehicle several times to stabilize the suspension, and then measure the vehicle height.

Standard Vehicle Height (Unloaded Vehicle):

Body Type	A (Front)	B (Rear)
Short	27 mm (1.06 in.)	105 mm (4.13 in.)
Semi Long	34 mm (1.34 in.)	83 mm (3.27 in.)
Long	34 mm (1.34 in.)	113 mm (4.45 in.)
Super Long Single Cab Standard Suspension Type	33 mm (1.30 in.)	130 mm (5.12 in.)
Super Long Single Cab Hard Duty Suspension Type	22 mm (0.87 in.)	132 mm (5.20 in.)
Super Long Double Cab Standard Suspension Type	35 mm (1.38 in.)	108 mm (4.25 in.)
Super Long Double Cab Hard Duty Suspension Type	25 mm (0.98 in.)	110 mm (4.33 in.)

Measuring points:

A:

Distance from the front axle housing to the follow spring


B:

Distance from the rear axle housing to the bumper stopper

If the vehicle height is not as specified, adjust the height by pressing down on the vehicle several times to stabilize the suspension.

3.INSPECT CAMBER, CASTER AND STEERING AXIS INCLINATION

a.



*a	Alignment Tester
*b	Gauge

Install a camber-caster-kingpin gauge or place the front wheels on the center of a wheel alignment tester.


- b.
- Inspect the camber, caster and steering axis inclination.
Standard Camber, Caster and Steering Axis Inclination (Unloaded Vehicle):

Item		Specified Condition
Camber Right-left error		1°00' +/-45' (1.00° +/-0.75°) 45' (0.75°) or less
Caster Right-left error	Except Super Long	4°20' +/-60' (4.33° +/-1.00°) 45' (0.75°) or less
	Super Long	3°35' +/-60' (3.58° +/-1.00°) 45' (0.75°) or less
Steering axis inclination		13°00' +/-45' (13.00° +/-0.75°)

If the caster and steering axis inclination are not as specified after the camber has been correctly adjusted, recheck the suspension parts for damage and/or wear.

4.INSPECT TOE-IN

a.



Front of the Vehicle




If the toe-in is not as specified, adjust the tie rod ends.

Standard Toe-in (Unloaded Vehicle):



A + B C - D
A + B: 0°00' +/-12' (0.00° +/-0.2°) C - D: 0 +/-2 mm (0.00 +/-0.0787 in.)

5.ADJUST TOE-IN

- Loosen the clamp bolts and nuts.
- Adjust the toe-in to the correct value by turning the tie rod.



Make sure that the lengths of the left and right tie rod ends are the same.



Tighten the clamp bolts and nuts.

Torque:


36.8 N*m (375 kgf*cm, 27 ft.*lbf)

HINT:

Make sure the clamp opening is positioned at the rear of the tie rod and facing within 10° from the vehicle axis.

6.INSPECT WHEEL ANGLE

a.



Turn the steering wheel fully, and measure the wheel angle.


Standard Wheel Angle (Unloaded Vehicle):

Inside wheel angle	Outside wheel angle (reference)
29°00' to 32°00' (29.00° to 32.00°)	28°00' (28.00°)

NOTICE:

When the steering wheel is fully turned, make sure that the wheel is not touching the body or brake flexible hose. If the maximum wheel angle differs from the standard value, adjust the wheel angle with the knuckle stopper bolts.

b.



Adjust the wheel angle.

- Loosen the lock nuts and adjust the wheel angle using the knuckle stopper bolts.

NOTICE:

The stopper bolts are installed to the front and back of the left and right side steering knuckles. When performing adjustments, the rear right side and front left side stopper bolts are considered to be a pair and the rear left side and front right side stopper bolts are considered to be a pair. When adjusting either of these bolt pairs, make sure that both of the stopper bolts are turned until they stop at the same time. After adjusting the wheel angle, there should not be any clearance between either of the bolts and the adjacent bracket.

If the wheel angle still cannot be adjusted to the standard value, inspect the steering parts and replace any damaged or worn parts as necessary.

- Tighten the lock nuts.

Torque:

44.1 N*m (450 kgf*cm, 33 ft.*lbf)