(Cont. next page)50 LAND CRUISER (LHD) (Cont'd)

(Cont. next page)50 LAND CRUISER (LHD) (Cont'd)

(Cont. next page)50 LAND CRUISER (LHD) (Cont'd)

(Cont. next page)50 LAND CRUISER (LHD) (Cont'd)


Power Source
Combination Meter (2UZ-FE, 1HD-FTE)
Combination Meter (2UZ-FE, 1HD-FTE)
Combination Meter (2UZ-FE, 1HD-FTE)
Combination Meter (2UZ-FE, 1HD-FTE)
*1: 2UZ-FE A/T
*2: 2UZ-FE M/T
*3: Forked 2UZ-FE
*4: Europe
*5: Except Europe
*4: Europe
*4: Europe
*4: Europe
*4: Europe
*5: Except Europe
*6: Automatic A/C
*7: Except *5
*8: Except *4
*9: w/o VSC
*10: w/ ABS
*11: w/o ABS
*12: Diesel
Suspension Control ECU-C3 RH
HDS & SA & TRC & VSC ECU-I3 RH
Combination Meter
Junction Connector
Body ECU
J24 Junction Connector
Sensor
Combination Meter
Front Left Side of Fender Apron
Rear Right Side of Right Cylinder Head
Rear Bank of Right Cylinder Head
Rear Bank of Left Cylinder Head
Front Left Side of Engine
Front Right Side of Fender Apron
Set Bolt of Cowl Side J/B RH
Set Bolt of Cowl Side J/B LH
Front Left Side of Fender Apron
Set Bolt of Cowl Side J/B LH
Set Bolt of Cowl Side J/B RH
Front Left Side of Fender Apron