

- В
- Fog Light Assembly LH
  Fog Light Assembly RH В
- 3 No.1 Ultrasonic Sensor RH 4 No.1 Ultrasonic Sensor LH В
- D 12 Starter Assembly
- D 13 Starter Assembly

## Position of Parts in Engine Compartment <RHD 1VD-FTV>











